



MBS-910LC

Metal Band Saw

JRM80910T

3~400V 50Hz


PARTS LIST




Импортер в РФ: ООО «ИТА Технолоджи»
105082, Москва, Переведеновский пер., д. 17
www.jettools.ru
Made in PRC / Сделано в КНР

P-JRM80910T 2025-09


Parts Breakdown for MBS-910LC Metal Band Saw-A




Parts Breakdown for MBS-910LC Metal Band Saw-B




Parts Breakdown for MBS-910LC Metal Band Saw-C



Parts Breakdown for MBS-910LC Metal Band Saw-D



Parts Breakdown for MBS-910LC Metal Band Saw-E



Parts List for MBS-910LC Metal Band Saw

Index No.	Part No.	Description	Size	Qty
1	MBS910LC-001	Right Base		1
2	GB/T6170	Hex.Nut	M12	2
3	GB/T5783	Hex. Cap Head Screw	M12x40	2
4	GB/T6170	Hex.Nut	M8	8
5	GB/T95	Flat Washer	8 mm	8
6	GB/T5783	Hex. Cap Head Screw	M8x16	8
7	MBS910LC-007	Base Plate		2
8	MBS910LC-008	Left Base		1
9	GB/T70.1	Hex Scocket Head Cap Screw	M8x20	2
10	GB/T95	Flat Washer	8 mm	4
11	GB/T70.1	Hex Scocket Head Cap Screw	M8x20	2
12	GB/T95	Flat Washer	8mm	2
13	GB/T6170	Hex.Nut	M8	2
14	MBS910LC-014	Plate		1
15	MBS910LC-015	Fixed Plate		1
16	GB/T6170	Hex Nut	M10	2
17	GB/T95	Flat Washer	10mm	2
18	GB/T5783	Hex. Cap Head Screw	M10x20	2
19	MBS910LC-019	Roller		1
20	MBS910LC-020	Spacer		2
21	GB/T95	Flat Washer	8 mm	2
22	GB/T70.1	Hex Scocket Head Cap Screw	M8x16	2
23	MBS910LC-023	Filter Net		1
24	GB/T70.1	Hex Scocket Head Cap Screw	M5x10	4
25	GB/T70.1	Hex Scocket Head Cap Screw	M6x10	2
26	GB/T95	Flat Washer	6mm	2
27	MBS910LC-027	Hose	Φ12XΦ8x1300mm	1
28	MBS910LC-028M2	Cooling Motor (M2)	3~400V 50Hz 45W	1
29	GB/T5783	Hex. Cap Head Screw	M10x20	4
30	MBS910LC-030	Base		1
31	GB/T5783	Hex. Cap Head Screw	M12x40	2
32	GB/T6170	Hex Nut	M12	2
33	GB/T70.1	Hex Scocket Head Cap Screw	M5x8	4
34	MBS910LC-034	Block Plate		1
35	MBS910LC-035	Shaft		1
36	GB/T276	Ball Bearing	6302-2Z	2
37	MBS910LC-037	Splash Guard		1
38	MBS910LC-038	Hand Wheel	Φ125XΦ15 Steel	1
39	GB/T77	Hex.Scocket Set Screw	M5x8	1
40	MBS910LC-040	Hex Nut		1
41	MBS910LC-041	Bearing Seat		1

Parts List for MBS-910LC Metal Band Saw

Index No.	Part No.	Description	Size	Q'ty
42	GB/T301	Thrust Bearing	51104	1
43	MBS910LC-043	Lock Handle		1
44	MBS910LC-044	Bush		1
45	GB/T70.1	Hex Scket Head Cap Screw	M6x100	2
46	MBS910LC-046	Upper Vise		1
47	MBS910LC-047	Plate		1
48	GB/T70.1	Hex Scket Head Cap Screw	M6x20	2
49	MBS910LC-049	Compressed Spring		1
50	MBS910LC-050	Lead Screw		1
54	MBS910LC-054	Lower Vise		1
55	MBS910LC-055	Rod		1
56	MBS910LC-056	Shaft For Stopper		1
57	MBS910LC-057	Block For Stopper		1
58	MBS910LC-058	Star Handle	M8x16	2
59	GB/T818	Phillips Head Screw	M5x8	2
60	MBS910LC-060	Scale Pointer		1
61	GB/T5783	Hex. Cap Head Screw	M10x30	1
62	GB/T6170	Hex Nut	M10	1
64	GB/T77	Hex.Scket Set Screw	M8x10	1
65	MBS910LC-065	Rotating Shaft		1
67	GB/T297	Bearing	32006	2
68	GB/T6170	Hex.Nut	M10	1
69	GB/T5783	Hex. Cap Head Screw	M10x30	1
70	MBS910LC-070	Eyelet Bolt	M12x40	1
71	MBS910LC-071	Dust Cap		1
72	GB/T858	Tab Washer for Round Nut	30mm	1
73	GB/T812	Round Nut	M30x1.5	1
78	GB/T818	Phillips Head Screw	M4x8	4
79	GB/T95	Flat Wahser	5mm	2
80	GB/T818	Phillips Head Screw	M5x8	2
81	MBS910LC-081	Electrical Box Cover		1
82	GB/T818	Phillips Head Screw	M5x8	2
83	MBS910LC-083	Electric Board		1
84	MBS910LC-084	Electrical Box		1
85	MBS910LC-085	Panel		1
86	MBS910LC-086	Support		1
88	GB/T70.1	Hex Scket Head Cap Screw	M5x12	4
89	GB/T70.1	Hex Scket Head Cap Screw	M8x20	6
90	GB/T95	Flat Washer	8mm	6
91	MBS910LC-091	Fixed Seat		1
92	MBS910LC-092	Scale		1

Parts List for MBS-910LC Metal Band Saw

Index No.	Part No.	Description	Size	Qty
93	GB/T827	Rivet	2x5	2
94	MBS910LC-094	Swivel Arm		1
95	MBS910LC-095	Fixed Seat		1
97	MBS910LC-097	Oil Seal 3.55X160		1
98	MBS910LC-098	Connecting Shaft		1
99	MBS910LC-099	Inner Sleeve		1
100	GB/T70.1	Hex Scocket Head Cap Screw	M8x30	4
101	GB/T93	Spring Washer	8mm	4
102	GB/T78	Hex.Scocket Set Screw	M8x10	1
103	GB/T70.1	Hex Scocket Head Cap Screw	M10x35	1
104	GB/T95	Flat Washer	10mm	1
105	GB/T77	Hex.Scocket Set Screw	M10x10	1
106	MBS910LC-106	Locking Lever		1
107	GB/T6170	Hex. Nut	M12	1
108	MBS910LC-108	Handle		1
109	GB/T70.1	Hex Scocket Head Cap Screw	M10x30	4
110	GB/T93	Spring Washer	10mm	4
111	MBS910LC-111	Press Plate		2
112	GB/T95	Flat Washer	8mm	6
113	GB/T70.1	Hex Scocket Head Cap Screw	M8x20	6
115	MBS910LC-115	Adjusting Bracket		1
116	GB/T77	Hex.Scocket Set Screw	M6x12	4
117	GB/T70.1	Hex Scocket Head Cap Screw	M8x25	2
118	GB/T70.1	Hex Scocket Head Cap Screw	M12x50	1
119	MBS910LC-119	Tighting Seat		1
120	GB/T70.1	Hex Scocket Head Cap Screw	M6x12	1
121	MBS910LC-121	Turning Handle M6x50		1
122	GB/T70.1	Hex Scocket Head Cap Screw	M6x12	2
123	MBS910LC-123	Guard Plate		1
124	MBS910LC-124	Slide Block		1
125	GB/T93	Spring Washer	10mm	3
126	GB/T70.1	Hex Scocket Head Cap Screw	M10x45	3
127	GB/T77	Hex.Scocket Set Screw	M10x16	1
128	GB/T6174	Hex. Thin Nut	M16	1
131	MBS910LC-131	Handle		2
132	MBS910LC-132	Handle Wheel		1
133	MBS910LC-133	Disc Spring	Φ36XΦ17X2	2
134	MBS910LC-134	Adjusting Lever		1
137	GB/T77	Hex.Scocket Set Screw	M8x10	2
138	MBS910LC-138	Handle		1
140	MBS910LC-140	Switch Handle		1

Parts List for MBS-910LC Metal Band Saw


Index No.	Part No.	Description	Size	Qty
141	MBS910LC-141	Shaft		1
142	GB/T297	Bearing 32006	32006	2
143	MBS910LC-143	Idle Wheel		1
145	GB/T858	Tab Washer for Round Nut	30mm	1
146	GB/T812	Hex Nut	M30X1.5	1
147	MBS910LC-147	Oil Cup M8X1		1
148	MBS910LC-148	Blade		1
149	MBS910LC-149	Blade Shield		1
150	GB/T70.1	Hex Scket Head Cap Screw	M6x12	4
151	GB/T70.1	Hex Scket Head Cap Screw	M4x8	2
153	GB/T95	Flat Washer	4mm	2
154	GB/T6170	Hex. Nut	M4	2
155	GB/T5783	Hex. Cap Head Screw	M10x25	1
156	GB/T93	Lock Washer	10mm	1
157	MBS910LC-157	Spacer		1
158	MBS910LC-158	Drive Wheel		1
161	MBS910LC-161	Hose	Φ9XΦ6x1300mm	1
163	MBS910LC-163	Cooling Block		1set
164	GB/T70.1	Hex Scket Head Cap Screw	M4x25	2
165	MBS910LC-165	Saw Bow		1
166	MBS910LC-166	Hex Shaft		1
167	MBS910LC-167	Connecting Plate		1
168	MBS910LC-168	Ajusting Handle		1
169	GB/T6174	Hex. Thin Nut M16		2
170	MBS910LC-170	Small Shaft		1
171	MBS910LC-171	Thread Shaft		1
172	MBS910LC-172	Tension Spring		1
173	GB/T77	Hex.Scket Set Screw	M8x10	3
174	GB/T1096	Flat Key	8x30	1
175	MBS910LC-175M1	Main Motor (M1) 3~ 400V 50Hz P2=0.75 / 1.1kW		1
176	GB/T95	Flat Washer	8mm	4
177	GB/T5783	Hex. Head Screw	M8x30	4
178	MBS910LC-178	Gear Box		1
179	GB/T77	Hex.Scket Set Screw	M6x12	4
181	GB/T70.1	Hex Scket Head Cap Screw	M8x25	2
182	MBS910LC-182	Guard Plate		1
183	GB/T70.1	Hex Scket Head Cap Screw	M6x12	2
184	GB/T6170	Hex.Nut	M6	2
185	MBS910LC-185	Set Screw		2
186	MBS910LC-186	Left Adjusting Block		1
187	MBS910LC-187	Right Angle Jointor		1

Parts List for MBS-910LC Metal Band Saw

Index No.	Part No.	Description	Size	Qty
188	MBS910LC-188	Blade Protection		1
189	MBS910LC-189	Blade Guide II		2
190	GB/T70.1	Hex Scket Head Cap Screw	M6x12	2
191	MBS910LC-191	Right Adjusting Block		1
192	MBS910LC-192	Pipe Fitting		1
193	GB/T77	Hex.Scket Set Screw	M6x20	2
194	GB/T70.1	Hex Scket Head Cap Screw	M6x12	2
195	GB/T95	Flat Washer	6mm	2
196	MBS910LC-196	Shaft Sleeve		1
197	GB/T77	Hex.Scket Set Screw	M6x6	1
198	MBS910LC-198	Bracket		1
199	MBS910LC-199	Brush		1
200	MBS910LC-200	Eccentric Shaft		2
201	GB/T276	Ball Bearing	608-2Z	8
202	MBS910LC-202	Blade Guide I		2
203	GB/T70.1	Hex Scket Head Cap Screw	M6x25	2
204	GB/T894.1	Retaining Ring	8mm	4
205	MBS910LC-205	Small Shaft		2
206	GB/T276	Ball Bearing	608-2Z	2
207	MBS910LC-207	Blade Tensionmeter		1
208	MBS910LC-208	Hydraulic Cylinder Seat (Upper)		1
209	GB/T70.1	Hex Scket Head Cap Screw	M8x25	4
210	GB/T93	Spring Washer	8mm	4
211	GB/T70.1	Hex Scket Head Cap Screw	M10x40	1
212	MBS910LC-212	Hydraulic Cylinder		1
213	GB/T6170	Hex. Nut	M10	1
214	GB/T77	Hex.Scket Set Screw	M5x8	1
215	MBS910LC-215	Hydraulic Cylinder Seat (Lower)		1
216	GB/T119.1	Round Pin	12x70	1
217	GB/T95	Flat Washer	8mm	2
218	GB/T70.1	Hex Scket Head Cap Screw	M8x25	2
219	GB/T70.1	Hex Scket Head Cap Screw	M4x25	2
220	MBS910LC-220	Limit Switch		1
221	GB/T70.1	Hex Scket Head Cap Screw	M4x12	1
222	MBS910LC-222	Bracket For Limit Switch		1
223	MBS910LC-223	Five-Pin Plug P551 & Power Cord 4G1.5mm ²		1
	MBS910LC-ID	JETRUS ID Label (Not shown)		1
	MBS910LC-ML	JETRUS Motor Label (Not shown)		1
	JETRUS-LOGO	JETRUS -165L (Not shown)	165x42mm	1
	MBS910LC-WR	Warning Label (Not shown)		1

Wiring Diagram for MBS-910LC Metal Band Saw

JRM80910T..... 3 ~ 400V, 50Hz



Parts list of MBS-910LC Metal Band Saw Electrical Circuit

Index No.	Code	Description	Type / Spec.	Q/ty	Remark
1	QF1	Breaker	DZ47-63 / 2P1A	1	JUCHE
2	QF2	Breaker	DZ47-63 / 1P1A	1	JUCHE
3	KM1	AC Contractor	CN-6 / 3A1a AC24V 9A	1	TECO
4	FR	Thermorelay	RHU-5M / 2.3-3.2A	1	JUCHE
5	SA1	Speed Conversion Switch	LW42B2-50001109 / LF301 C22 / 20A	1	
6	SA2	Pump Switch	XB2-ED21 / 3A	1	
7	TC	Transformer	JBK5-60 / 400 230/24V	1	JUCHE
8	TA	Emergency Stop	XB2-BS542 / 3A	1	
9	SB1	Start Button	XB2-EA31 / 3A	1	
10	SQ1	Key Switch	QKS8 / 8A	1	
11	SQ2	Limited Switch	QKS7 / 8A	1	
12	EL1	Power Light	XB2-BVB1C / AC24V	1	
13	MBS910LC-175M1	Main Motor (M1), 3~ 400V 50Hz P2=0.75 / 1.1kW		1	
14	MBS910LC-028M2	Cooling Motor (M2)	3~400V 50Hz 45W	1	
15	MBS910LC-223	Five-Pin Plug	P551 400V	1	
16	MBS910LC-223	Power Cord	4G1.5mm ² 2.5m	1	

