



JBSM-150

Belt Sander for Metal

JBSM-150 50001892T ~400V 50Hz

JBSM-150 50001892M ~230V 50Hz


PARTS LIST

Импортер в РФ: ООО «ИТА Технолоджи»
105082, Москва, Переведеновский пер., д. 17
www.jettools.ru

Made in PRC / Сделано в КНР

P- 50001892 M T 2025-09

Part Breakdown for JBSM-150 Belt Sander for Metal



Part List for JBSM-150 Belt Sander for Metal


Index No.	Part No.	Description	Size	Qty.
1	JBSM150-001	Cup Head Screw	M4x6	8
2	JBSM150-002	Left Cover		1
3	JBSM150-003	Work Table		1
4	JBSM150-004	Fixation Board Of Work Table		1
5	JBSM150-005	Flat Washer	8	1
6	JBSM150-006	Pan Head Screw	M8x12	2
7	JBSM150-007	Pan Head Screw	M8x16	4
8	JBSM150-008	U-Support		1
9	JBSM150-009	Body		1
10	JBSM150-010	Dust Receiver		1
11	JBSM150-011	Driven Wheel		1
12	JBSM150-012	Star Grip Screw		2
13	JBSM150-013	Spring		2
14	JBSM150-014	Position Tube		2
15	JBSM150-015	Spring Washer	8	3
16	JBSM150-016	Self-Locking Nut	M8	2
17	JBSM150-017	Spring Washer	8	9
18	JBSM150-018	Driven Wheel Guide		1
19	JBSM150-019	Columnar Pin	Ø6x50	1
20	JBSM150-020	Hex Bolt	M8x20	1
21	JBSM150-021	Shaft Block		1
22	JBSM150-022	Hand Wheel		1
23	JBSM150-023	Hexl Socket Screw	M6x25	1
24	JBSM150-024	Spring		1
25	JBSM150-025	Retaining Ring	Ø47	2
26	JBSM150-026	Bearing	6204	2
27	JBSM150-027	Driven Wheel Shaft		1
28	JBSM150-028	Washer	8	6
29	JBSM150-029	Hex Bolt	M8 x18	2
30	JBSM150-030	Cup Head Screw	M4x8	2
31	JBSM150-031	Washer	4	2
32	JBSM150-032	Perspective Plate		1
33	JBSM150-033	Collecting Board		2
34	JBSM150-034	Cup Head Screw	M6x50	1
35	JBSM150-035	Black Lead Plate		1
36	JBSM150-036	Hex Bolt	M8x12	2
37	JBSM150-037	Fence Extensions		1
38	JBSM150-038	Self-Locking Nut	M6	1
39	JBSM150-039	Nut	M4	2
40	JBSM150-040T	Motor	400V 4.0kW	1
	JBSM150-040M	Motor	230V 2.8kW	1
	JBSM150-040RC	Running Capacitor	50uf 450V	1
	JBSM150-040JB	Junction Box		1
	JBSM150-040JC	Junction Box Cover		1
41	JBSM150-041	Hex Bolt	M8x20	4
42	JBSM150-042	Hand Ball		1
43	JBSM150-043	Safety Cover		1
44	JBSM150-044	Top Table		1
45	JBSM150-045	Right Cover		1
46	JBSM150-046	Side Fence		1
47	JBSM150-047	Protect Tube		1
48	JBSM150-048	Pin	3x20	1
49	JBSM150-049	Spring		1
50	JBSM150-050	Hand Bar		1
51	JBSM150-051	Base		1
52	JBSM150-052	Washer		1
53	JBSM150-053	Lock Knob		1
54	JBSM150-054	Lock Shaft		1
55	JBSM150-055	Screw	M6x16	1
56	JBSM150-056	Hex Socket Screw	M5x20	1
57	JBSM150-057	Sand Belt		1

Part List for JBSM-150 Belt Sander for Metal

Index No.	Part No.	Description	Size	Qty.
58	JBSM150-058	Big Washer	Φ32	1
59	JBSM150-059	Drive Wheel		1
60	JBSM150-060	Cup Head Screw	M8x20	2
61	JBSM150-061	Spring Washer	8	2
62	JBSM150-062	Hex Bolt	M8x12	3
63	JBSM150-063	Hand Bar Collecting Rod		1
64	JBSM150-064	Handle		1
65	JBSM150-065	Cup Head Screw	M4x60	4
66	JBSM150-066	Hinge		4
67	JBSM150-067	Cup Head Screw	M4x6	16
68	JBSM150-068	Cup Head Screw	M4x12	2
70	JBSM150-070	Spring Plate		1
71	JBSM150-071	Emergency Stop Switch		1
72	JBSM150-072T	Switch & Plug	400V	1
	JBSM150-072M	Switch & Plug	230V	1
73	JBSM150-073	Motor Cover		1
74	JBSM150-074	Motor Fan		1
75	JBSM150-075	Key		1
	JBSM150-ID	ID Label (not Shown)	400V	1
	JBSM150-ID	ID Label (not Shown)	230V	1
	JBSM150-ML	Motor Label (not Shown)	400V	1
	JBSM150-ML	Motor Label (not Shown)	230V	1
	JBSM150-WR	Warning Label		1
	JET LOGO	JET-165	165x64mm	1

Wiring Diagram for JBSM-150 Belt Sander for Metal

50001892M..... ~ 230V, 50Hz



50001892T..... ~ 400V, 50Hz

